





COSTUMER IS TO ENSURE THAT DURING POUR OPERATIONS CONCRETE IS PLACED IN AN EVEN MANNER PREVENTING THE IMBALANCE OF ANY FORCES. CONCRETE PLACEMENT IS TO BE CONTROLLED TO AVOID ADVERSE FORCES FROM HEAPING, SURGE AND IMPACT.



Fast-Form www.fastformsystems.com info@fastformsystems.com

Tel South: 00 44 (0) 0203 507 1832 / 507 1833 / 507 1834

Tel North: 00 44 (0) 1472 488230 / 488660 / 485640



Made in Britain

IMPORTANT:

Omega Business Park

Estate Road 6

Grimsby

N.E.Lincs

DN31 2TG

tighten all tensile bolts with an 18v impact wrench !!! TIGHTEN ALL CONCRETE BOLTS WITH A 110V IMPACT WRENCH !!!

LEGAL NOTICE:

Fast Form [™] is the Trade Mark of Fast-Form Systems Ltd and all designs are copyright and intellectual property of Fast-Form Systems Ltd and may not be reproduced or used without permission. Fast Form ™ is covered by the following Patents: granted GB2508263 / GB2533172 Patents Pending GB 1616005.3 / GB 1506126.0 / US-2016-0194887 / PCT W02016 / 110663 / EP 14780541.0 / PCT GB2014 / 052586. Copyright or Trade Mark infringements will be prosecuted, If you see any similar bracket in operation without our name on it please send us an email to info@fastformsystems.com we offer a reward for all successful prosecutions.

IMPORTANT:

CONSULT YOUR TEMPORARY WORKS DEPARTMENT

BEFORE USING THIS DESIGN FOR CONSTRUCTION.





MINIMUM THICKNESS AND STRENGTH OF CONCRETE BLINDING FOR INSTALLATION OF CONCRETE BOLTS IS SPECIFIED IN THE MANUFACTURER'S TECHNICAL APPROVAL AND INSTALLATION GUIDES. ALL BOLTS TO BE TIGHTENED WITH A 110V IMPACT WRENCH!

PLYWOOD TO BE MIN. 18MM EXTERIOR STRUCTURAL GRADE.

POSITION THE PLYWOOD JOINTS TO FALL ON CENTRE OF THE UPRIGHTS AND HORIZONTAL JOINING MEMBERS.

PLYWOOD TO BE FIXED TO THE UPRIGHTS AND HORIZONTAL JOINING MEMBERS FROM THE BACK WITH 25MM WOOD SCREWS.

APPLY CONCRETE RELEASE AGENT / MOULD OIL TO FACE OF PLYWOOD PRIOR TO POURING CONCRETE.

CONCRETE TO BE POURED AND COMPACTED IN MAX. 1000MM THICK LAYERS PER HOUR.



CORRECT POSITIONING OF THE PROPS IS ESSENTIAL FOR THE FORMWORK TO RESIST CONCRETE PRESSURE!

CORRECT POSITION OF CONCRETE BOLTS: I:5







IMPORTANT:

ALL CONCRETE HOLDING DOWN BOLTS TO BE INSTALLED ACCORDING TO THE MANUFACTURER TECHNICAL APPROVAL AND INSTALLATION GUIDES AND INTO STRUCTURALLY SOUND CONCRETE TO ENSURE A SECURE FIXING.

NT:					
IN I. PORARY WORKS DEPARTMENT DESIGN FOR CONSTRUCTION.	REVISION DATE		DESCRIPTION		Signed
	0	4/06/15	ORIGINAL VERSION		K.P.
	Α	4/06/16	ANNUAL REVISION		K.P.
Drawn By: Karol Podsiadlo Date: 04/06/15 Rev: A					
Designed by: Karol Podsiadlo Drawing no: FFS-19WS3					
Project: 1.9m Fast Form Wall System Single sided					
Drawing title: Cross-section View					