

IMPORTANT NOTES:

MAKE SURE THAT EACH UPPER BRACKET IS POSITIONED EXACTLY OVER THE SUPPORT BRACKET AND FIXED THROUGH PLYWOOD WITH TENSILE BOLTS !!!.

THE BOTTOM SHUTTER PLYWOOD HAS TO BE CUT OUT WITH A JIGSAW, USING A TEMPLATE TO FORM THE SHAPE OF THE RECESSES OF THE SHEET PILING. USE SILICONE SEALANT TO PREVENT ANY GROUT FROM LEAKING OUT.



Drawn By: Karol
Designed by: To
Project: One Side
Drawing title: Sid



